



**PLEASE NOTE THAT THE WAY THE KIT IS PACKED DOES NOT NECESSARILY REPRESENT THE WAY OF MOUNTING TO THE BIKE**

### **Fitting Instructions for CP0108BL Crash Protectors**

#### **Aprilia RSV '04- / Tuono Rears**

**Please note that in cases where kits are packed with rubber washers holding the components onto the bolt – *the rubber washers should be thrown away!***

- Undo nearside (left hand side) rear engine bolt (15mm ring spanner required inside)
- Remove bolt
- Offer R & G bobbin up to bike (the bobbin with the longer neck)
- Slide R & G bar through centre of bobbin and into engine, slide M10 washer and nyloc (finger tight) on exposed end of bar. Ensure shorter thread is to the outside of the bike
- Slide bar through as far as it will go
- Slide M10 washer on bar
- Screw on nyloc and tighten whole assembly.
- Tighten bolt until you feel some compression from inside the protector. Turn a little more so that you feel the compression increase slightly. Then apply a quarter turn. Do not overtighten as damage can occur to the bike. Do not exceed 40nm of torque.
- Repeat for **offside** (right hand side as you sit on the bike), but using the bobbin with the shorter neck

*Due to the risk of cross threading of bolts etc; we recommend that our products be fitted by one of our official dealers or a qualified mechanic.*

#### **CONSUMER NOTICE**

The catalogue description and any exhibition of samples are only broad indications of the Products and R&G may make design changes which do not diminish their performance or visual appeal and supplying them in such state shall conform to the order. The Buyer acknowledges no representation or warranty (other than as to title) has been given or will apply to the Products other than those in R&G's order or confirmation and the Buyer confirms it has chosen the Products as being of merchantable quality and suitable for its particular purposes. Where R&G fits the Products or undertakes other services it shall exercise reasonable skill and care and rectify any fault free of charge unless the workmanship has been disturbed. The Buyer is responsible for ensuring that the warranty on the motorcycle is not affected by the fitting of the Products. On return of any defective Products R&G shall at its option either supply a replacement or refund the purchase money but shall not be liable if the Products have been modified or used or maintained otherwise than in accordance with R&G's or manufacturer's instructions and good engineering practice or if the defect arises from accident or neglect. Other than identified above and subject to R&G not limiting its liability for causing death and personal injury, it shall not be liable for indirect or consequential loss and otherwise its liability shall be limited to the amounts paid by the Buyer for the Products or the fitting or service concerned. These terms do not affect the Buyer's statutory rights.

#### **R&G RACING RETURNS POLICY (NON-FAULTY GOODS)**

Returns must be pre-authorized (if not pre-authorized the return will be rejected). Goods may only be returned direct to us if they were purchased direct from us (customer must prove if necessary). Otherwise to be returned to original vendor. Goods must be in re-sellable condition, in the opinion of R&G Racing. All returns are subject to a 25% restocking and handling fee (25% of the gross value exc. P&P – at the prevailing price at time of purchase). The customer must pay any and all carriage charges. No returns of discontinued products, unless within 14 days of purchase. This policy does not affect your statutory rights and does not refer to faulty goods.

R&G Racing

Unit 5K, Blacknest Industrial Park, Blacknest Road, Alton, Hampshire, GU34 4PX

Tel: +44 (0)870 220 6380 Fax: +44 (0)1420 521101 [www.rg-racing.com](http://www.rg-racing.com) Email: [info@rg-racing.com](mailto:info@rg-racing.com)



## Notice de montage

**CP0108** APRILIA 1000 RSV FACTORY 04-

ARRIERE

Le sens de montage n'est pas identique au sens présenté dans l'emballage, merci de suivre les instructions ci dessous.

Dans le cas où les kits sont emballés avec un joint torique, celui-ci doit être retiré avant le montage.



### Conseil de montage:

- œ Désérrez la vis de fixation moteur à l'arrière côté gauche, (utilisez une clé à pipe de 15 mm)
- œ Enlevez la vis
- œ Placez le tampon R&G (ayant la collerette la plus petite) dans le renforcement du cadre.
- œ Glissez une partie de la barre R&G dans le tampon (le filetage le plus court sera positionné vers l'extérieur de la moto.)
- œ Glissez une rondelle et un écrou M10 (autobloquant) sur l'axe R&G, (serrez l'écrou à la main.)
- œ Poussez l'axe dans le tampon
- œ Serrez ensuite l'ensemble sur la moto.
- œ Serrez l'écrou jusqu'à ce que vous sentiez de la compression à l'intérieur de la protection. Tournez encore un peu et vous sentirez la compression augmenter, faite un quart de tour. Ne pas trop serrer car cela pourrait abîmer la moto. Ne pas exéder 40nm de couple de serrage.

*Pour le côté droit, faite les mêmes opérations que pour le côté gauche, vous devrez utiliser le tampon ayant la colerette la plus grande.*

R&G Racing

Unit 5K, Blacknest Industrial Park, Blacknest Road, Alton, Hampshire, GU34 4PX

Tel: +44 (0)870 220 6380 Fax: +44 (0)1420 521101 [www.rg-racing.com](http://www.rg-racing.com) Email: [info@rg-racing.com](mailto:info@rg-racing.com)